

AGRI DRAIN



1462 340th St. Adair, IA 50002

6

641-742-5211 800-232-4742

 \sim

www.agridrain.com info@agridrain.com


Anti-Seep Collars 🎏

Keep your pipe from being washed out.

- The Anti-Seep Collar works with any smoothwall pipe or corrugated plastic tubing.
- ¹/₁₆" gum rubber.
- Easy to install.
- Tan floating stock has superior resilience, elongation, and tear strength.
- Resistant to water, most salts, mild acids, and many other chemicals.
- Wood frame.
- Economical to buy.



Size	Item#	Recommended Pipe Sizes
2' x 2'	ASC02	3"
3' x 3'	ASC03	4", 5", 6", 8", 10", 12"
4' x 4'	ASC04	15", 18", 24"
5' x 5'	ASC05	30", 36"
6' x 6'	ASC06	42", 48", 60"



Gum Rubber

Physical Properties:

Tensile: 3000 Elongation: 600

Temperature: -20° F to +140° F

Finish: Smooth

Specifications:
ASTM D2000
SAE J200
1AA 430

Directions for Using The Anti-Seep CollarInstructions come with each collar.

- Unroll Anti-Seep Collar and align boards to form a square. Attach metal brackets to corner of the boards with screws provided. Attach rubber to frame with nails provided.
- 2. *IMPORTANT—Cut a round hole in the center of rubber that is smaller than pipe size (approx. 33% smaller). This will allow rubber to stretch over pipe when Anti-Seep Collar is installed on pipe. This will provide a tight seal between pipe and Anti-Seep Collar.
 - *Cutting an "X" or slit will cause the rubber to tear.
- Slip pipe through Anti-Seep Collar, inspect seal between pipe and Anti-Seep Collar, carefully backfill, and compact with suitable soil.

CAUTION: Excessive compaction or downward pressure on wooden frame will cause rubber to stretch and distort resulting in loss of seal between rubber and pipe.